

## P. LEO ELECTRICAL INSULATION SYSTEM, UL File E200050

(click on a System to view details)

Designation	Class	Voltage
<a href="#">B81</a>	130(B)	600V
<a href="#">B82</a>	130(B)	600V
<a href="#">B83</a>	130(B)	600V
<a href="#">B85</a>	130(B)	600V
<a href="#">B86</a>	130(B)	600V
<a href="#">B88</a>	130(B)	600V
<a href="#">B89</a>	130(B)	600V
<a href="#">B90</a>	130(B)	600V
<a href="#">B91</a>	130(B)	600V
<a href="#">B92</a>	130(B)	600V
<a href="#">B93</a>	130(B)	600V
<a href="#">B95</a>	130(B)	600V
<a href="#">B96</a>	130(B)	600V
<a href="#">B97-Table I</a>	130(B)	600V
<a href="#">B97-Table II</a>	130(B)	600V
<a href="#">B98-Table I</a>	130(B)	600V
<a href="#">B98-Table II</a>	130(B)	600V
<a href="#">F81</a>	155(F)	600V
<a href="#">F82</a>	155(F)	600V
<a href="#">F83</a>	155(F)	600V
<a href="#">F88</a>	155(F)	600V
<a href="#">F89</a>	155(F)	600V
<a href="#">F90</a>	155(F)	600V

<a href="#">F91</a>	155(F)	600V
<a href="#">H82</a>	180(H)	600V
<a href="#">H83</a>	180(H)	600V
<a href="#">H84</a>	180(H)	600V
<a href="#">H85</a>	180(H)	600V
<a href="#">H86</a>	180(H)	600V
<a href="#">H87</a>	180(H)	600V
<a href="#">HV-1</a>	220(R)	15KV
<a href="#">HV-2</a>	220(R)	34.5KV
<a href="#">N82</a>	200(N)	600V
<a href="#">N83</a>	200(N)	600V
<a href="#">N85</a>	200(N)	600V
<a href="#">N86</a>	200(N)	600V
<a href="#">N88</a>	200(N)	600V
<a href="#">N89</a>	200(N)	600V
<a href="#">N90</a>	200(N)	600V
<a href="#">N91</a>	200(N)	600V
<a href="#">R81</a>	220(R)	600V
<a href="#">R82</a>	220(R)	600V
<a href="#">S81</a>	240(S)	600V
<a href="#">S82</a>	240(S)	600V